

DESIGN VERIFICATION TEST REPORT

Test Item Interscale M

Identification Interscale M 14825-197
Fan ebm-papst 412
Fan ebm-papst 412H

Test Order Determine the total air flow and the acoustic noise of the case

Reported by Daniel Dörflinger

Date 21.08.2013

Signature



Daniel Dörflinger
Head of Test Lab Climate Control

Schroff GmbH
Langenalber Str. 96 - 100
75334 Straubenhardt,
Germany Office
+49.7082.794.624
Fax +49.7082.794.493
daniel.doerflinger@nvent.com

This report consists of 23 numbered pages. The examination results are only related to the equipment under test. This material is proprietary of Schroff GmbH. Any unauthorized reproduction, use or disclosure of this material, or any part thereof, is strictly prohibited. This material is meant solely for the use by Schroff employees and authorized Schroff customers.

Table of contents

1. Assessment.....	4
2. Description of the test.....	4
2.1 Sample(s)	5
2.2 Test resources/equipment	6
2.3 Fan Comparison	8
3. Results	9
3.1 Pull cooling with ebm-papst 412 and without impedance	9
3.2 Pull cooling with ebm-papst 412 and with impedance	10
3.3 Advice-1	11
3.5 Push cooling with ebm-papst 412 and without impedance	12
3.6 Push cooling with ebm-papst 412 and with impedance	13
3.7 Advice-2	14
3.8 Comparison Push vs. Pull ebm-papst 412.....	15
3.9 Pull cooling with ebm-papst 412H and without impedance.....	16
3.10 Pull cooling with ebm-papst 412H and with impedance.....	17
3.11 Advice-3	18
3.12 Push cooling with ebm-papst 412H and without impedance	19
3.13 Push cooling with ebm-papst 412H and with impedance	20
3.14 Advice-4	21
3.15 Comparison Push vs. Pull ebm-papst 412H	22
3.16 Résumé	22
4. Acoustic Noise	23

List of figures

Figure 1 Interscale case fixed to Test stand for air flow volume measurement - 1	5
Figure 2 Interscale case fixed to Test stand for air flow volume measurement - 2	5
Figure 3 Test stand for air volume measurements.....	6
Figure 4 Power supply	6
Figure 5 Measurement equipment	6
Figure 6 Test equipment acoustic noise measurements.....	7
Figure 7 Power supply	7
Figure 8 Single Fan comparison	8
Figure 9 Pull cooling without Impedance-1	9
Figure 10 Pull cooling with impedance-2	10
Figure 11 Pull cooling with impedance-1	10
Figure 12 Advice-1.....	11
Figure 13 Push cooling without Impedance-1	12
Figure 14 Push cooling with Impedance-1	13
Figure 15 Advice-2	14
Figure 16 Comparison Push vs. Pull ebm-papst 412.....	15
Figure 17 Pull cooling without Impedance-2	16
Figure 18 Pull cooling with Impedance-2	17
Figure 19 Advice-3.....	18
Figure 20 Push cooling without Impedance-2.....	19
Figure 21 Push cooling with Impedance-2.....	20
Figure 22 Advice-4.....	21
Figure 23 Comparison Push vs. Pull ebm-papst 412H	22
Figure 24 Measurement setup Acoustic Noise-1	23
Figure 25 Measurement setup Acoustic Noise-2	23

List of tables

Table 1 Pull cooling without impedance-1	9
Table 2 Pull cooling with impedance-1	10
Table 3 Push cooling without impedance-1	12
Table 4 Push cooling with Impedance-1	13
Table 5 Pull cooling without impedance-2	16
Table 6 Pull cooling with impedance-2	17
Table 7 Push cooling without impedance-2	19
Table 8 Push cooling with Impedance-2	20
Table 9 Résumé	22
Table 10 Acoustic Noise	23

1. Assessment

In this report you will find the measurement results of the **total air volume** of the case. The case was tested with the **test stand for air flow volume measurements** (description see page 6) at **normal operation**.

Furthermore you will find the measurement results of the **acoustic noise measurement**. The case was tested at **normal operation**. The description of the test equipment see page 7.

2. Description of the test

On the one hand the case was fixed to the **test stand for air volume measurements**. Operating voltage of the fans was 12V DC and the operating conditions for the fans were **maximum speed**.

On the other hand the case was placed on the floor and tested with the **sound intensity measuring method**. Operating voltage of the fans was 12V DC and the operating conditions for the fans were also **maximum speed and the measurement distance was 0,2m**.

2.1 Sample(s)

The Interscale case was equipped with following components:

- 5x axial fans, ebm-papst 412 and ebm-papst 412H




Figure 1 Interscale case fixed to Test stand for air flow volume measurement - 1



Figure 2 Interscale case fixed to Test stand for air flow volume measurement - 2

2.2 Test resources/equipment

Total air flow (Test stand for air flow volume measurements)

- Chamber test stand works on the vacuum side in accordance to DIN 24163
- Specially developed from the university of Cologne (Germany)
- Measurements:
 - Air flow volume of fans in cases, cabinets and systems
 - Determination, air drag characteristic curves of filter mats, perforations and openings
 - Fan comparison, air flow volume, speed, power input, power, AC, DC clamping
- Output characteristic curves of fans with characteristic drag curves or characteristic systems curves
- Measurement equipment for the wind tunnel, Linseis Datalogger
- Power supply EA-PS 9080



Figure 3 Test stand for air volume measurements




Figure 4 Power supply



Figure 5 Measurement equipment

Test equipment acoustic noise

- Measurement of the sound intensity in accordance to DIN EN ISO 9614-2
- Determination of the sound power with the results from the sound intensity measurement
- Measurement in all rooms with constant background sound possible
- Determination of frequency spectrums of all measurement areas
- Measurement of sound pressure level
- Measurement of mechanical vibration (oscillating acceleration) with acceleration sensor
- Sound Intensity Investigator B & K – 2260
- Microphone B & K – 4181
- Sound Level Calibrator B & K - 4231
- Power supply EA-PS 9080



Figure 6 Test equipment acoustic noise measurements




Figure 7 Power supply

2.3 Fan Comparison




Figure 8 Single Fan comparison

3. Results

3.1 Pull cooling with ebm-papst 412 and without impedance




Figure 9 Pull cooling without Impedance-1

	without Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	31	18

Table 1 Pull cooling without impedance-1

3.2 Pull cooling with ebm-papst 412 and with impedance



Figure 11 Pull cooling with impedance-1




Figure 10 Pull cooling with impedance-2

	with Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	31	18

Table 2 Pull cooling with impedance-1

3.3 Advice-1

To get the best working point for the fans, the distance between air inlet and impedance has to be approx. 20,0mm.




Figure 12 Advice-1

3.5 Push cooling with ebm-papst 412 and without impedance




Figure 13 Push cooling without Impedance-1

	without Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	36	21

Table 3 Push cooling without impedance-1

3.6 Push cooling with ebm-papst 412 and with impedance




Figure 14 Push cooling with Impedance-1

	with Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	36	21

Table 4 Push cooling with Impedance-1

3.7 Advice-2

To get the best working point for the fans, the distance between air outlet and impedance has to be approx. 20,0mm.




Figure 15 Advice-2

3.8 Comparison Push vs. Pull ebm-papst 412




Figure 16 Comparison Push vs. Pull ebm-papst 412

3.9 Pull cooling with ebm-papst 412H and without impedance




Figure 17 Pull cooling without Impedance-2

	without Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	37	21

Table 5 Pull cooling without impedance-2

3.10 Pull cooling with ebm-papst 412H and with impedance




Figure 18 Pull cooling with Impedance-2

	with Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	37	21

Table 6 Pull cooling with impedance-2

3.11 Advice-3

To get the best working point for the fans, the distance between air inlet and impedance has to be approx. 20,0mm.




Figure 19 Advice-3

3.12 Push cooling with ebm-papst 412H and without impedance




Figure 20 Push cooling without Impedance-2

	without Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	45	26

Table 7 Push cooling without impedance-2

3.13 Push cooling with ebm-papst 412H and with impedance




Figure 21 Push cooling with Impedance-2

	without Impedance	
	[m ³ /h]	[cfm]
Bulk air flow	45	26

Table 8 Push cooling with Impedance-2

3.14 Advice-4

To get the best working point for the fans, the distance between air outlet and impedance has to be approx. 20,0mm.




Figure 22 Advice-4

3.15 Comparison Push vs. Pull ebmpapst 412H




Figure 23 Comparison Push vs. Pull ebmpapst 412H

3.16 Résumé

	ebm-papst 412				ebm-papst 412H			
	Pull cooling		Push cooling		Pull cooling		Push cooling	
	[m³/h]	[cfm]	[m³/h]	[cfm]	[m³/h]	[cfm]	[m³/h]	[cfm]
Without Impedance	31	18	36	21	37	21	45	26
With Impedance	31	18	36	21	37	21	45	26

Table 9 Résumé

4. Acoustic Noise

Fan	Sound Power L_{WA} [dB(A)]	Sound Pressure L_{PA} [dB(A)] 0,2m distance
ebm-papst 412	50,7	51,7
ebm-papst 412H	57,3	58,1

Table 10 Acoustic Noise




Figure 24 Measurement setup Acoustic Noise-1




Figure 25 Measurement setup Acoustic Noise-2